
## INSTRUCTIONS



Step 1: Take out the clip.



Step 2: Insert the dupont line.



Step 3: Push out the clip

## OPERATING SKILLS

The method of holding small chip pin:
Wobble the hand gently and push forward slightly.

To push out the clip andgently remove it from the chip pin.

Ξ: If it can't hold the chip pin, please refer to the picture.

Adjust the front end of the clip with tweezers to make the angle close to 90 degrees.

